

**PRINTRONIX®**

---

***OKI® Programmer's Reference Manual***



---

*OKI<sup>®</sup> Programmer's Reference Manual*

**PRINTRONIX<sup>®</sup>**

---

Printronix, Inc. makes no representations or warranties of any kind regarding this material, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. Printronix, Inc. shall not be held responsible for errors contained herein or any omissions from this material or for any damages, whether direct, indirect, incidental or consequential, in connection with the furnishing, distribution, performance or use of this material. The information in this manual is subject to change without notice.

This document contains proprietary information protected by copyright. No part of this document may be reproduced, copied, translated or incorporated in any other material in any form or by any means, whether manual, graphic, electronic, mechanical or otherwise, without the prior written consent of Printronix, Inc.

**Copyright © 2012 Printronix, Inc.**

All rights reserved.

## Trademark Acknowledgements

---

Printronix, IGP, PGL, LinePrinter Plus, and PSA are registered trademarks of Printronix, Inc.

OKI and Oki Data are registered trademarks of Oki Electric Industry Company, Ltd.



# Table of Contents

<b>1</b>	<b>Introduction .....</b>	<b>9</b>
	About this Manual .....	9
	Printer Configuration Compatibility .....	10
	Menus Supported .....	10
	Menus Not Supported .....	11
<b>2</b>	<b>Supported Commands .....</b>	<b>13</b>
	Printer Disk Control Command Functions .....	13
	Horizontal Motion Command Functions.....	14
	Vertical Motion Command Functions.....	15
	Character and Graphic Control Command Functions.....	16
	Printing Mode Command Functions .....	16
	DBCS Command Functions.....	18
	Extended Command Functions .....	19
<b>3</b>	<b>Fully Compatible Commands.....</b>	<b>21</b>
	Printer Disk Control Commands .....	21
	Printer Select (DC1).....	21
	Printer Deselect (DC3).....	21
	Cancel Line (CAN).....	21
	Initalize Printer (DLE B) .....	21
	Emulation Switch (ESC / n) .....	21
	Horizontal Motion Commands .....	22
	Carriage Return (CR).....	22
	Left Movement (ESC % 4 n1 n2 and ESC # 4 n1 n2).....	22
	Back Space (BS) .....	22
	Set Absolute Print Position (ESC %6 n1 n2 and ESC #6 n1 n2) .....	22
	Right Movement (ESC %3 n1 n2 and ESC #3 n1 n2) .....	22
	Set Left Margin (ESC ( n1 n2) .....	22
	Set Right Margin (ESC ) n1 n2) .....	22
	Set Horizontal Tab (ESC L) .....	22
	Execute Horizontal Tab (HT) .....	22

Vertical Motion Commands.....	23
Line Feed (LF) .....	23
Set 1/6-Inch Line Spacing (ESC 6).....	23
Set 1/8-Inch Line Spacing (ESC 8).....	23
Reversed Form Feed n/120" (ESC % 8 n and ESC # 8 n) .....	23
Set Line Space By 1/120" (ESC %(# 9 n1 n2).....	23
Set Vertical Movement in Lines (ESC VT n1 n2).....	23
Feed Forward n/120" (ESC %(# 5 n).....	23
Form Feed (FF) .....	23
Set Page Length (ESC F n1 n2) .....	23
Set Form Length by Lines (ESC C n) .....	23
Set Form Length in Inch by 1/120" (ESC J n1 n2).....	23
Set Top of Form (ESC 5).....	23
Set Vertical Tab (DC4).....	23
Execute Vertical Tab (VT).....	24
Set Bottom Margin (ESC G n1 n2) .....	24
Character and Graphic Commands.....	24
Send Graphic Data (ESC % 1 nHnL d1 ... dk and ESC # 1 nHnLd1 ... dk).....	24
Send Double Width Expansion Graphic Data (ESC % 2 nHnLd1 ... dk and ESC #2 nHnLd1 ... dk).....	24
Printer Mode Commands.....	24
Select Print Quality - High Speed (ESC D).....	24
Select Print Quality - High Density (ESC I).....	24
Turn on Underline (ESC X).....	24
Turn Off Underline (ESC Y) .....	24
Turn on Double-Width Printing (ESC U) .....	24
Turn off Double-Width Printing (ESC R) .....	24
Select Half Width Printing (ESC <) .....	25
Cancel Half Width Printing (ESC >).....	25
Turn on Double-Height Printing (ESC [) .....	25
Turn off Double-Height Printing (ESC ]) .....	25
Turn on Triple-Height Printing (ESC e).....	25
Turn off Triple-Height Printing (ESC f).....	25
Turn on Triple-Width Printing (ESC g).....	25
Turn off Triple-Width Printing (ESC h).....	25
Select Bold Font (ESC i).....	25
Cancel Bold Font (ESC j).....	25
Select Double-Strike Printing (ESC m).....	25
Select Double-Strike Printing (ESC n).....	25
Set Unidirectional Printing (ESC % U and ESC # U).....	25
Set Bidirectional Printing (ESC % B and ESC # B) .....	26

DBCS Commands .....	26
Set DBCS Mode (ESC \$ @) .....	26
Reset DBCS Mode (ESC ( H) .....	26
Set DBCS InterCharacter Spacing (CEX \$ n) .....	26
Set Expansion Font Typeface (CEX 0 n1 n2) .....	26
Defined User-Defined Chinese Character (CEX 2 a1 a2 d1 d2 d3 ... d72) .....	26
Select Vertical Printing (CEX J) .....	26
Select Horizontal Printing (CEX K) .....	26
Select Superscript Printing (CEX N) .....	26
Cancel Superscript Printing (CEX O) .....	26
Select Subscript Printing (CEX P) .....	26
Cancel Subscript Printing (CEX Q) .....	26
Select Super/Subscript Printing (CEX R) .....	27
Cancel Super/Subscript Printing (CEX S) .....	27
Pair Two ASCII Characters in Vertical Print Mode (CEX -) ....	27
DBCS Double Width Print (CEX p) .....	27
Cancel DBCS Double Width Print (CEX q) .....	27
Set DBCS Half Width Mode (CEX r) .....	27
Cancel DBCS Half Width Mode (CEX s) .....	27
Disable DBCS ASCII Vertical Printing Mode (CEX t) .....	27
Enable SBCS Vertical Printing Mode (CEX u) .....	27
Set Shift JIS Mode (ESC k) .....	27
Cancel Shift JIS Mode (ESC l) .....	27
Extension Commands (ESC   15H 07H 00H P1 P2 P3 P4 P5 P6 0) .....	27
<b>4 Partially Compatible Commands.....</b>	<b>29</b>
Character Set Commands .....	29
12 Points (10 CPI) HS ANK Character Set (ESC N) .....	29
12 Points (10 CPI) HD ANK Character Set (ESC H) .....	29
Select 12 CPI HS ANK Character Set (ESC B) .....	29
Select 12 CPI HD ANK Character Set (ESC E) .....	29
<b>5 Unimplemented or Ignored Commands .....</b>	<b>31</b>
Confirm Print End (ESC b) .....	31
Set Single Paper Orientation (ESC T) .....	31
Paper Out Detection Control (ESC Z) .....	31
Low Noise Printing (ESC O) .....	31
Set Color Mode (ESC c) .....	31
Select Hiragana ANK Mode (ESC &) .....	31
Select Katakana ANK Mode (ESC ') .....	31

<b>A Contact Information.....</b>	<b>33</b>
Printronic Customer Support Center.....	33
Printronic Supplies Department.....	33
Corporate Offices.....	34



---

# 1

# *Introduction*

## **About this Manual**

---

This manual describes OKI language support, functionality, and compatibility in Printronix Line Matrix H-Series printers. The OKI emulation allows users to replace a serial matrix printer (with OKI emulation) with a PTX Line Matrix H-Series printer without modifying its current operating environment.

OKI printer model references are Microline 6100F and Microline 6300F.

**NOTE:** Not all OKI commands and menu options are fully implemented.

The ESC/PK emulation in the OKI ML6300F printer is not supported.

OKI windows drivers which use the ESC/PK emulation are not supported.

## Printer Configuration Compatibility

Table 1 lists the OKI configuration settings and describes their behavior on OKI ML6300 printers and corresponding Printronix menu settings.

### Menus Supported

**Table 1. Supported OKI menus for OKI ML6300 and Printronix Printers**

Menu Option	OKI ML6300	Printronix
Emulation	OKI*/Epson	Emulation ->LP+->OKI
DBCS Mode	Yes*/No	Emulation->LP+->FontAttr.->DBCS/ASCII Mode
Buffer Size	0, 64K	Buffer size under Host Interface
Page Length	279.4mm* (11 inch), 296.3mm...	Emulation->LP+->Form Length
LF	LF only/CR+LF*	Emulation->LP+->OKI->Define LF Code
CR	CR only/CR+LF	Emulation->LP+->OKI->Define CR Code
Slash Zero	Yes/No*	Emulation->LP+->Font Attributes->Slashed Zero
Printing Direction	Uni-direction/Bi-direction*	Printer Control->Unidirectional
Characters per line	80/106*	Emulation -> LP+ -> Page Format -> Form Width -> Function of CPI
Printing Direction Control Command	Enable*/Disable	Emulation->LP+->Host Command->Ignore Unidir.
Print Mode	Normal*/High Speed	Emulation->LP+->Font Attributes->>Typeface
High Speed Printing	High Speed*/Super HS/ Ultra HS	Emulation->LP+->Font Attributes->>Typeface
Line Spacing	6LPI*/8LPI	Emulation->LP+->CPI/LPI Select->Select LPI
Printing Adjustment	Normal/High Speed/ Super High Speed/Ultra High Speed	Diagnostics->Printer Test->Phase Printer

## Menus Not Supported

Table 2. Non-supported OKI menus for OKI ML6300 and Printronix Printers

Menu Option	OKI ML6300	Printronix
Compression	100%* / 75% / 50%	
Character Size	Normal/Double Width/ Double Height/Two By Two	
Form Length Adjust	-4.23mm~-0.35mm, 0, 0.35mm~4.23mm	<b>NOTE:</b> N7000 supports Form Length Setting in 0.1mm increments.
Form Length Adjust2	-4~-1, 0, 1~4 (0.07mm)	
Paper Out Detect	Enable/Disable	<b>NOTE:</b> N7000 always enables the paper out fault detection.
Cutter Position Adjust	-7, -6, ...0, 1, ..., 7	<b>NOTE:</b> N7000 does not have a cutter menu option.
TOF Position (Single Sheet Paper)	2.12mm (1/12"), ..., 6.35mm (3/12")*, ...	<b>NOTE:</b> N7000 does not support single sheet paper.
TOF Position Adjust (Single Sheet Paper)	-7, ..., -1, 0, 1, ..., 7	<b>NOTE:</b> N7000 does not support single sheet paper.
TOF Position (Continuous Paper)	2.12mm (1/12"), ..., 6.35mm (3/12")*, ...	
TOF Position Adjust (Continuous)	-7, ..., -1, 0, 1, ..., 7	
Table Printing Mode	Standard/Special	<b>NOTE:</b> There is no difference on the OKI printer for the Standard/Special option.
Feed Paper Waiting Time (Single Sheet Paper)	0.5s, 1.0s, 2.0s	<b>NOTE:</b> N7000 does not support single sheet paper.
Printing Position	Printing/Cutter Position	<b>NOTE:</b> N7000 does not support the cutter option.
Cutter	Manual/0.5s/1.0s/2.0s	<b>NOTE:</b> N7000 does not support the cutter option.
Character Styling	Song/Hei	<b>NOTE:</b> N7000 supports the Song option only.

Table 2. Non-supported OKI menus for OKI ML6300 and Printronix Printers

Menu Option	OKI ML6300	Printronix
Numeric Styling	Standard/Banking/Small	<b>NOTE:</b> Not supported in N7000.
Process FF when TOF	Enable/Disable	
Init Signal Processing		
LF Adjust in Single Sheet Paper		<b>NOTE:</b> N7000 does not support single sheet paper.

---

# 2

## *Supported Commands*

This chapter explains how to support OKI language compatibility.

### **Printer Disk Control Command Functions**

---

**Table 3. Printer Disk Control Commands**

<b>Command</b>	<b>Description</b>	<b>Compatibility</b>	<b>Reference</b>
DC1	Printer Select	Full	page 21
DC3	Printer Deselect	Full	page 21
CAN	Cancel Line	Full	page 21
ESC b	Confirm Printer End	Ignored, Hardware Limitation (Not supported on ML6300F printers)	page 31
ESC T	Single Sheet Paper Feed Direction	Ignored, Hardware Limitation	page 31
ESC Z	Paper Out Detect	Ignored, Command Not Implemented	page 31
DLE B	Initialize Printer	Full	page 21
ESC /	Emulation Switch	Full	page 21

## Horizontal Motion Command Functions

Table 4. Horizontal Motion Commands

Command	Description	Compatibility	Reference
CR	Carriage Return	Full	page 22
ESC % 4	Left Movement	Full	page 22
ESC # 4			
BS	Backspace	Full	page 22
ESC % 6	Sets Absolute Horizontal Print Position	Full	page 22
ESC # 6			
ESC % 3	Right Movement	Full	page 22
ESC # 3			
ESC (	Sets Left Margin	Full	page 22
ESC )	Sets Right Margin	Full	page 22
ESC L	Sets Horizontal Tab	Full	page 22
HT	Executes Horizontal Tab	Full	page 22

## Vertical Motion Command Functions

**Table 5. Vertical Motion Commands**

<b>Command</b>	<b>Description</b>	<b>Compatibility</b>	<b>Reference</b>
LF	Line Feed	Full	page 23
ESC 6	Line Spacing 1/16 inch (6 lpi)	Full	page 23
ESC 8	Line Spacing 1/8 inch (8 lpi)	Full	page 23
ESC% 8	Reverses Form Feed n/120 inch	Full	page 23
ESC # 8			
ESC% 9	Line Spacing n/120 inch	Full	page 23
ESC # 9			
ESC VT	Sets Vertical Movement in Lines	Full	page 23
ESC % 5	Feeds Forward n/120 inch	Full	page 23
ESC # 5			
FF	Form Feed	Full	page 23
ESC F	Sets Form Length by Lines	Full	page 23
ESC C	Sets Form Length by Lines	Full	page 23
ESC J	Sets Form Length by 1/120 inch	Full	page 23
ESC 5	Sets TOF	Full	page 23
DC4	Sets Vertical Tab	Full	page 23
VT	Executes Vertical Tab	Full	page 24
ESC G	Sets Bottom Margin	Full	page 24

## Character and Graphic Control Command Functions

Table 6. Character and Graphic Control Commands

Command	Description	Compatibility	Reference
ESC N	12 point (pt) HS ANK Char Set	Partially Compatible	page 29
ESC H	12 point (pt) HD ANK Char Set	Partially Compatible	page 29
ESC B	Character Size HS ANK Char Set	Partially Compatible	page 29
ESC E	Character Size HD ANK Char Set	Partially Compatible	page 29
ESC &	Hiragana ANK Char Set	Ignored, Command Not Implemented	page 31
ESC '	Katakana ANK Char Set	Ignored, Command Not Implemented	page 31
ESC % 1	Sends Graphic Data	Full	page 24
ESC # 1			
ESC % 2	Sends Double Width Expansion Graphic Data	Full	page 24
ESC # 2			

## Printing Mode Command Functions

Table 7. Printing Mode Control Commands

Command	Description	Compatibility	Reference
ESC D	Selects Print Quality High Speed	Full	page 24
ESC H	Selects Print Quality High Density	Full	page 24
ESC O	Selects Print Quality Low Noise	Ignored, Hardware Limitation	page 31
ESC X	Sets Underline	Full	page 24
ESC Y	Cancel Underline	Full	page 24
ESC U	Sets Double Wide Print	Full	page 24
ESC R	Cancel Double Wide Print	Full	page 24
ESC <	Sets Horizontal 1/2 Condensed Print	Full	page 25
ESC >	Cancel Horizontal 1/2 Condensed Print	Full	page 25



---

**Table 7. Printing Mode Control Commands**

<b>Command</b>	<b>Description</b>	<b>Compatibility</b>	<b>Reference</b>
ESC [	Sets Double High Print	Full	page 25
ESC ]	Cancel Double High Print	Full	page 25
ESC e	Sets Triple High Print	Full	page 25
ESC f	Cancel Triple High Print	Full	page 25
ESC g	Sets Triple Wide Print	Full	page 25
ESC h	Cancel Triple Wide Print	Full	page 25
ESC i	Sets Emphasized Print	Full	page 25
ESC j	Cancel Emphasized Print	Full	page 25
ESC m	Sets Double Strike	Full	page 25
ESC n	Cancel Double Strike	Full	page 25
ESC % U	Sets Unidirectional Print	Full	page 25
ESC # U			
ESC % B	Sets Bidirectional Print	Full	page 26
ESC # B			
ESC c	Color Mode	Ignored, Hardware Limitation	page 31

## DBCS Command Functions

**Table 8. DBCS Commands**

Command	Description	Compatibility	Reference
ESC \$ @	Sets DBCS Mode	Full	page 26
ESC ( H	Cancel DBCS Mode	Full	page 26
CEX \$	Sets Intercharacter Spacing in DBCS	Full	page 26
CEX 0	Sets Extended Font Typeface	Full	page 26
CEX 2	User-Defined DBCS Character	Full	page 26
CEX J	Selects DBCS Vertical Printing	Full	page 26
CEX K	Selects DBCS Horizontal Printing	Full	page 26
CEX N	Sets DBCS Superscript Print	Full	page 26
CEX O	Cancel DBCS Superscript Print	Full	page 26
CEX P	Sets DBCS Subscript Print	Full	page 26
CEX Q	Cancel DBCS Subscript Print	Full	page 26
CEX R	Sets DBCS Superscript and Subscript Print	Full	page 27
CEX S	Cancel DBCS Superscript and Subscript Print	Full	page 27
CEX _	Sets Vertical Half Width Combined Mode	Full	page 27
CEX p	Sets DBCS Double Wide Print	Full	page 27
CEX q	Cancel DBCS Double Wide Print	Full	page 27
CEX r	Sets DBCS Half-Width Print	Full	page 27
CEX s	Cancel DBCS Half-Width Print	Full	page 27
CEX t	Disables Vertical Half-Width Print	Full	page 27
CEX u	Enables Vertical Half-Width Print	Full	page 27
ESC k	Sets Shift JIS Mode	Full	page 27
ESC l	Cancel Shift JIS Mode	Full	page 27

---

## Extended Command Functions

---

Table 9. Extended Commands

Command	Description	Compatibility	Reference
ESC I	Selects Print Mode	Full	page 27



---

# 3

## *Fully Compatible Commands*

The commands in this chapter are fully compatible with the OKI emulation. The following sections list fully supported commands with valid parameters.

### **Printer Disk Control Commands**

---

#### **Printer Select (DC1)**

Places printer in select state.

#### **Printer Deselect (DC3)**

Places printer in deselect state.

#### **Cancel Line (CAN)**

Clears all printable data in the current line without affecting the control code.

#### **Initialize Printer (DLE B)**

Sets the printer's initial condition.

#### **Emulation Switch (ESC / n)**

Switches between LQ1600K and OKI emulation.

## Horizontal Motion Commands

---

### **Carriage Return (CR)**

Moves the print position to the left margin position.

### **Left Movement (ESC % 4 n1 n2 and ESC # 4 n1 n2)**

Moves the horizontal print position to the left of the current position.

### **Back Space (BS)**

Moves the print position to the left a distance equal to one character space.

### **Set Absolute Print Position (ESC %6 n1 n2 and ESC #6 n1 n2)**

Moves the horizontal print position to an absolute print position.

### **Right Movement (ESC %3 n1 n2 and ESC #3 n1 n2)**

Moves the horizontal print position to the right from the current position.

### **Set Left Margin (ESC ( n1 n2)**

Sets the left margin to specified inches.

### **Set Right Margin (ESC ) n1 n2)**

Sets the right margin to specified inches.

### **Set Horizontal Tab (ESC L)**

Sets the horizontal tab position as measured from the left edge.

### **Execute Horizontal Tab (HT)**

Moves the horizontal print position to the next tab to the right of the current print position.

---

## Vertical Motion Commands

---

### **Line Feed (LF)**

Advances the vertical print position one line at the current line spacing.

### **Set 1/6-Inch Line Spacing (ESC 6)**

Sets the line spacing to 1/6 inch.

### **Set 1/8-Inch Line Spacing (ESC 8)**

Sets the line spacing to 1/8 inch.

### **Reversed Form Feed n/120" (ESC % 8 n and ESC # 8 n)**

Reverses Form Feed by n/120 inch.

### **Set Line Space By 1/120" (ESC %(# 9 n1 n2)**

Sets the line spacing to n2/120 inch.

### **Set Vertical Movement in Lines (ESC VT n1 n2)**

Sets vertical movement positions at the current line space by specified lines.

### **Feed Forward n/120" (ESC %(# 5 n)**

Feeds paper forward by n/120 inch.

### **Form Feed (FF)**

Advances the vertical print position to the top of the next form.

### **Set Page Length (ESC F n1 n2)**

Sets the page length to specified lines at the current line spacing.

### **Set Form Length by Lines (ESC C n)**

Sets the page length to specified lines at the current line spacing.

### **Set Form Length in Inch by 1/120" (ESC J n1 n2)**

Sets the page length to specified inches in increments of 1/120 inch.

### **Set Top of Form (ESC 5)**

Sets the current print position as the top of form (TOF).

### **Set Vertical Tab (DC4)**

Sets the vertical tab positions at the current line space by specified lines.

### **Execute Vertical Tab (VT)**

Moves the vertical print position to the next vertical tab position.

### **Set Bottom Margin (ESC G n1 n2)**

The printer will skip a number of specified lines from the bottom line and feed directly to the next TOF.

## **Character and Graphic Commands**

---

### **Send Graphic Data (ESC % 1 n<sub>H</sub>n<sub>L</sub> d<sub>1</sub> ... d<sub>k</sub> and ESC # 1 n<sub>H</sub>n<sub>L</sub> d<sub>1</sub> ... d<sub>k</sub>)**

Prints dot graphics in 24-dot columns.

### **Send Double Width Expansion Graphic Data (ESC % 2 n<sub>H</sub>n<sub>L</sub> d<sub>1</sub> ... d<sub>k</sub> and ESC #2 n<sub>H</sub>n<sub>L</sub> d<sub>1</sub> ... d<sub>k</sub>)**

Prints double width graphic data.

## **Printer Mode Commands**

---

### **Select Print Quality - High Speed (ESC D)**

Selects Normal typeface.

### **Select Print Quality - High Density (ESC I)**

Selects LQ typeface.

### **Turn on Underline (ESC X)**

Turns on printing of a line below all characters.

### **Turn Off Underline (ESC Y)**

Turns off printing of a line below all characters.

### **Turn on Double-Width Printing (ESC U)**

Turns on double width printing of all characters, spaces, and intercharacter spacing.

### **Turn off Double-Width Printing (ESC R)**

Turns off double width printing of all characters, spaces, and intercharacter spacing.



---

### **Select Half Width Printing (ESC <)**

This command reduces character width and intercharacter spacing by half its original size.

### **Cancel Half Width Printing (ESC >)**

Cancels half width printing and sets the width to normal.

### **Turn on Double-Height Printing (ESC [)**

Turns on double height printing of all characters.

### **Turn off Double-Height Printing (ESC ])**

Turns off double-height printing of all characters.

### **Turn on Triple-Height Printing (ESC e)**

Turns on triple height printing of all characters.

### **Turn off Triple-Height Printing (ESC f)**

Turns off triple height printing of all characters.

### **Turn on Triple-Width Printing (ESC g)**

Turns on triple width printing of all characters, space, and intercharacter spacing.

### **Turn off Triple-Width Printing (ESC h)**

Turns off triple width printing of all characters, space, and intercharacter spacing.

### **Select Bold Font (ESC i)**

Sets the font attribute to bold print.

### **Cancel Bold Font (ESC j)**

Turns off bold printing set by ESC i.

### **Select Double-Strike Printing (ESC m)**

Makes characters bolder by printing each dot twice.

### **Select Double-Strike Printing (ESC n)**

Turns off double strike printing set by ESC m.

### **Set Unidirectional Printing (ESC % U and ESC # U)**

Selects unidirectional printing.

### **Set Bidirectional Printing (ESC % B and ESC # B)**

Selects bidirectional printing.

## **DBCS Commands**

---

### **Set DBCS Mode (ESC \$ @)**

Sets the printer to DBCS mode and GB High Byte to OFF.

### **Reset DBCS Mode (ESC ( H)**

Cancels the effect of setting DBCS mode and sets the printer to ASCII mode.

### **Set DBCS InterCharacter Spacing (CEX \$ n)**

Sets the intercharacter space to the right of the DBCS/ASCII character.

### **Set Expansion Font Typeface (CEX 0 n1 n2)**

Sets the parameters for user defined graphic data.

### **Defined User-Defined Chinese Character (CEX 2 a1 a2 d1 d2 d3 ... d72)**

Defines the graphic data.

### **Select Vertical Printing (CEX J)**

The character prints in the same position with counterclockwise 90 degrees rotation.

### **Select Horizontal Printing (CEX K)**

Cancels vertical printing.

### **Select Superscript Printing (CEX N)**

Prints following characters at half the normal height. The printing location is the upper part of the character space.

### **Cancel Superscript Printing (CEX O)**

Cancels superscript printing selected by the CEX N command.

### **Select Subscript Printing (CEX P)**

Prints following characters at half the normal height. The printing location is the lower part of character space.

### **Cancel Subscript Printing (CEX Q)**

Cancels subscript printing selected by the CEX P command.

### **Select Super/Subscript Printing (CEX R)**

Prints following characters at half the normal height. The printing location is set at the upper part of the character space then the lower part of the character space.

### **Cancel Super/Subscript Printing (CEX S)**

Cancels superscript/subscript printing selected by the CEX R command.

### **Pair Two ASCII Characters in Vertical Print Mode (CEX -)**

Aligns two rotated ASCII characters to fit the space occupied by a normal size rotated character.

### **DBCS Double Width Print (CEX p)**

Doubles the DBCS characters and intercharacter spacing width. This function affects DBCS characters only.

### **Cancel DBCS Double Width Print (CEX q)**

Cancels double width printing.

### **Set DBCS Half Width Mode (CEX r)**

Sets the printing of DBCS characters as half width.

### **Cancel DBCS Half Width Mode (CEX s)**

This command cancels DBCS Half Width mode set by the CEX r command.

### **Disable DBCS ASCII Vertical Printing Mode (CEX t)**

Prints DBCS ASCII characters horizontally when Vertical Printing mode is set by the CEX J command.

### **Enable SBCS Vertical Printing Mode (CEX u)**

Prints DBCS ASCII characters counterclockwise vertically 90 degrees when Vertical Printing mode is set by the CEX J command.

### **Set Shift JIS Mode (ESC k)**

Sets to DBCS mode with MSB set to ON.

### **Cancel Shift JIS Mode (ESC l)**

Turns MSB off when the printer is in DBCS mode.

## **Extension Commands (ESC | 15H 07H 00H P1 P2 P3 P4 P5 P6 0)**

---

Selects the printing mode.



---

# 4

## *Partially Compatible Commands*

### **Character Set Commands**

---

#### **12 Points (10 CPI) HS ANK Character Set (ESC N)**

Selects 10 CPI HS ANK character set in ASCII mode.

Differences with OKI printer: no characters in range from 166 to 223.

#### **12 Points (10 CPI) HD ANK Character Set (ESC H)**

Selects 10 CPI HD ANK character set in ASCII mode.

Differences with OKI printer: no characters in range from 166 to 223.

#### **Select 12 CPI HS ANK Character Set (ESC B)**

Selects 12 CPI character set in ASCII mode.

Differences with OKI printer: no characters in range from 166 to 223.

#### **Select 12 CPI HD ANK Character Set (ESC E)**

Selects 12 CPI HD character set in ASCII mode.

Differences with OKI printer: no characters in range from 166 to 223.



---

# 5

## *Unimplemented or Ignored Commands*

The commands listed in this chapter will be unimplemented or ignored in the PTX\_OKI emulation. Some of these commands may be implemented in the future, while others are ignored due to hardware and software limitation. All of the unimplemented commands will be accepted without error, but will not take effect.

### **Confirm Print End (ESC b)**

This command indicates the end of printing. It will affect the BUSY signal in parallel port data. This command is ignored due to hardware differences.

### **Set Single Paper Orientation (ESC T)**

This command in OKI ML6300F sets the orientation for single paper size such as A4. This command is ignored due to hardware and mechanical differences.

### **Paper Out Detection Control (ESC Z)**

Paper out is detected when the end of paper supply is sensed. This command is ignored due to hardware differences.

### **Low Noise Printing (ESC O)**

Sets low noise printing mode. This command is ignored due to hardware differences.

### **Set Color Mode (ESC c)**

The command is invalid in OKI ML6300F printers.

### **Select Hiragana ANK Mode (ESC &)**

Selects Hiragana ANK character set overlay in ASCII mode. This command is unimplemented.

### **Select Katakana ANK Mode (ESC ')**

Selects Katakana ANK character set overlay in ASCII mode. This command is unimplemented.





---

# A

## Contact Information

---

### Printronix Customer Support Center

---

**IMPORTANT** Please have the following information available prior to calling the Printronix Customer Support Center:

- Model number
- Serial number (located on the back of the printer)
- Installed options (i.e., interface and host type if applicable to the problem)
- Configuration printout:

Line Matrix Printer

Press PRT CONFIG on the control panel, then press Enter.

- Is the problem with a new install or an existing printer?
- Description of the problem (be specific)
- Good and bad samples that clearly show the problem (faxing of these samples may be required)

Americas (714) 368-2686

Europe, Middle East, and Africa (31) 24 6489 410

Asia Pacific (65) 6548 4114

China (86) 800-999-6836

<http://www.primtronix.com/support.aspx>

---

### Printronix Supplies Department

---

Contact the Printronix Supplies Department for genuine Printronix supplies.

Americas (800) 733-1900

Europe, Middle East, and Africa 33 (0) 1 46 25 19 07

Asia Pacific (65) 6548 4116  
or (65) 6548 4182

China (86) 400-886-5598

<http://www.primtronix.com/supplies-parts.aspx>

## Corporate Offices

---

Printronix, Inc.  
14600 Myford Road  
P.O. Box 19559  
Irvine, CA 92623-9559  
Phone: (714) 368-2300  
Fax: (714) 368-2600

Printronix, Inc.  
Nederland BV  
P.O. Box 163, Nieuweweg 283  
NL-6600 Ad Wijchen  
The Netherlands  
Phone: (31) 24 6489489  
Fax: (31) 24 6489499

Printronix Schweiz GmbH  
42 Changi South Street 1  
Changi South Industrial Estate  
Singapore 486763  
Phone: (65) 6542 0110  
Fax: (65) 6546 1588

Printronix Commercial (Shanghai) Co. Ltd  
22F, Eton Building East  
No.555, Pudong Av.  
Shanghai City, 200120, P R China  
Phone: (86) 400 886 5598  
Fax: (86-21) 5138 0564

Visit the Printronix web site at [www.primtronix.com](http://www.primtronix.com)

---

# Index

## Numerics

- 12 Points (10 CPI) HD ANK Character Set (ESC H), 29
- 12 Points (10 cpi) HS ANK Character Set (ESC N), 29

## B

- Back Space (BS), 22

## C

- Cancel Bold Font (ESC j), 25
- Cancel DBCS Double Width Print (CEX q), 27
- Cancel DBCS Half Width Mode (CEX s), 27
- Cancel Half Width Printing (ESC >), 25
- Cancel Line (CAN), 21
- Cancel Shift JIS Mode (ESC I), 27
- Cancel Subscript Printing (CEX Q), 26
- Cancel Superscript Printing (CEX O), 26
- Cancel Superscript/Subscript Printing (CEX S), 27
- Carriage Return (CR), 22
- Character and Graphic Commands
  - send double width expansion graphic data, 24
  - send graphic data, 24
- Character Command Functions, 16
- Character Commands, 24
- Character Set Commands, 29
  - 12 points (10 CPI) HD ANK character set (ESC H), 29
  - 12 points (10 cpi) HS ANK character set (ESC N), 29
  - Select 12 CPI HD ANK character set (ESC E), 29
  - select 12 CPI HS ANK character set (ESC B), 29

- character set commands, 29
- Command Functions
  - character commands, 16
  - DBCS commands, 18
  - extended commands, 19
  - graphic control commands, 16
  - horizontal motion, 14
  - printer disk control, 13
  - printing mode commands, 16
  - vertical motion, 15

- Commands
  - supported, 13
- Compatibility, printer configuration, 10
- Confirm Print End (ESC b), 31

## D

- DBCS Command Functions, 18
- DBCS Commands, 26
  - cancel DBCS double width print (CEX q), 27
  - cancel DBCS half width mode (CEX s), 27
  - cancel shift JIS mode (ESC I), 27
  - cancel subscript printing (CEX Q), 26
  - cancel superscript printing (CEX O), 26
  - cancel superscript/subscript printing (CEX S), 27
- DBCS double width print (CEX p), 27
- defined user-defined chinese character (CEX 2 a1 a2 d1 d2 d3...d72), 26
- disable DBCS ASCII vertical printing mode (CEX t), 27
- enable SBCS vertical printing mode (CEX u), 27
- pair two ASCII characters in vertical print mode (CEX -), 27
- printer disk control commands, 26

reset DBCS mode (ESC (H), 26  
select horizontal printing (CEX K), 26  
select subscript printing (CEX P), 26  
select super/subscript printing (CEX R), 27  
select superscript printing (CEX N), 26  
select vertical printing (CEX J), 26  
set DBCS half width mode (CEX r), 27  
set DBCS intercharacter spacing (CEX \$ n), 26  
set DBCS mode (ESC \$ @), 26  
set expansion font typeface (CEX 0 n1 n2), 26  
set shift JIS mode (ESC k), 27

DBCS Double Width Print (CEX p), 27

Defined User-Defined Chinese Character  
(CEX 2 a1 a2 d1 d2 d3...d72), 26

Disable DBCS ASCII Vertical Printing Mode  
(CEX t), 27

## E

Emulation Switch (ESC / n), 21

Enable SBCS Vertical Printing Mode (CEX u), 27

Execute Horizontal Tab (HT), 22

Execute Vertical Tab (VT), 24

Extended Command Functions, 19

Extension Commands, 27

printer disk control commands, 27

## F

Feed Forward n/120" (ESC % (#) 5 n), 23

Form Feed (FF), 23

Fully Compatible Commands, 21

character commands, 24

graphic commands, 24

horizontal motion commands, 22

printer disk control commands, 21

printer mode commands, 24

vertical motion commands, 23

## G

Graphic Commands, 24

Graphic Control Command Functions, 16

## H

Horizontal Motion Command Functions, 14

Horizontal Motion Commands

back space (BS), 22

carriage return (CR), 22

execute horizontal tab (HT), 22

left movement (ESC% 4 n1 n2 and  
ESC# 4 n1 n2), 22

right movement (ESC %3 n1 n2 and  
ESC #3 n1 n2), 22

set absolute print position (ESC %6 n1 n2 and  
ESC #6 n1 n2), 22

set horizontal tab (ESC L), 22

set left margin (ESC ( n1 n2), 22

set right margin (ESC ) n1 n2), 22

## I

Ignored Commands, 31

confirm print end (ESC b), 31

paper out detection control (ESC O), 31

paper out detection control (ESC Z), 31

select Hiragana ANK mode (ESC &), 31

select Katakana ANK mode (ESC '), 31

set color mode (ESC c), 31

set single paper orientation (ESC T), 31

Initialize Printer (DLE B), 21

## L

Left Movement (ESC% 4 n1 n2 and  
ESC# 4 n1 n2), 22

Line Feed (LF), 23

## P

Pair Two ASCII Characters in Vertical Print Mode  
(CEX -), 27

Paper Out Detection Control (ESC O), 31

Paper Out Detection Control (ESC Z), 31

Partially Compatible Commands, 29

Printer Configuration Compatibility, 10

menus not supported, 11

menus supported, 10

Printer Deselect (DC3), 21

---

Printer Disk Control Command Functions, 13

Printer Disk Control Commands, 21

- cancel line (CAN), 21

- emulation switch (ESC / n), 21

- initialize printer (DLE B), 21

- printer deselect (DC3), 21

- printer select (DC1), 21

Printer Horizontal Motion Commands, 22

Printer Mode Commands, 24

Printer Select (DC1), 21

Printing Mode Command Functions, 16

Printing Mode Commands

- cancel bold font (ESC j), 25

- cancel half width printing (ESC >), 25

- select bold font (ESC i), 25

- select double-strike printing (ESC m), 25

- select double-strike printing (ESC n), 25

- select half width printing (ESC, 25

- select print quality high density (ESC I), 24

- select print quality high speed (ESC D), 24

- set unidirectional printing

  - (ESC % B and ESC # B), 26

- set unidirectional printing

  - (ESC % U and ESC # U), 25

- turn off double-height printing (ESC J), 25

- turn off double-width printing (ESC R), 24

- turn off triple-height printing (ESC f), 25

- turn off underline (ESC Y), 24

- turn on double-height printing, 25

- turn on double-width printing (ESC U), 24

- turn on triple-height printing (ESC e), 25

- turn on triple-width printing (ESC g), 25

- turn on triple-width printing (ESC h), 25

- turn on underline (ESC X), 24

## R

Reset DBCS Mode (ESC (H), 26

Reversed Form Feed n/120" (ESC %8 n and ESC #8 n), 23

Right Movement (ESC %3 n1 n2 and ESC #3 n1 n2), 22

## S

Select 12 CPI HD ANK Character Set (ESC E), 29

Select 12 CPI HS ANK Character Set (ESC B), 29

Select Bold Font (ESC i), 25

Select Double-Strike Printing (ESC m), 25

Select Double-Strike Printing (ESC n), 25

Select Half Width Printing (ESC, 25

Select Hiragana ANK Mode (ESC &), 31

Select Horizontal Printing (CEX K), 26

Select Katakana ANK Mode (ESC '), 31

Select Print Quality High Density (ESC I), 24

Select Print Quality High Speed (ESC D), 24

Select Subscript Printing (CEX P), 26

Select Super/Subscript Printing (CEX R), 27

Select Superscript Printing (CEX N), 26

Select Vertical Printing (CEX J), 26

Send Double Width Expansion Graphic Data, 24

Send Graphic Data, 24

Set 1/6 Inch Line Spacing (ESC 6), 23

Set 1/8 Inch Line Spacing (ESC 8), 23

Set Absolute Print Position (ESC %6 n1 n2 and ESC #6 n1 n2), 22

Set Bottom Margin (ESC G n1 n2), 24

Set Color Mode (ESC c), 31

Set DBCS Half Width Mode (CEX r), 27

Set DBCS InterCharacter Spacing (CEX \$ n), 26

Set DBCS Mode (ESC \$ @), 26

Set Expansion Font Typeface (CEX 0 n1 n2), 26

Set Form Length by Lines (ESC C n), 23

Set Form Length in Inch by 1/120"

  - (ESC J n1 n2), 23

Set Horizontal Tab (ESC L), 22

Set Left Margin (ESC ( n1 n2), 22

Set Line Space by 1/120" (ESC %(# 9 n1 n2), 23

Set Page Length (ESC F n1 n2), 23

Set Right Margin (ESC ) n1 n2), 22

Set Shift JIS Mode (ESC k), 27

Set Single paper Orientation (ESC T), 31

Set top of Form (ESC 5), 23

Set Unidirectional Printing (ESC % B and ESC # B), 26

---

Set Unidirectional Printing (ESC % U and ESC # U), 25  
Set Vertical Movement in Lines (ESC VT n1 n2), 23  
Set Vertical Tab (DC4), 23  
Supported Commands, 13

- Character Commands, 16
- DBCS Commands, 18
- Extended Commands, 19
- Graphic Control Commands, 16
- Horizontal Motion Commands, 14
- Printer Disk Control Commands, 13
- Printing Mode Commands, 16
- Vertical Motion Commands, 15

## T

Turn off Double-Height Printing (ESC J), 25  
Turn off Double-Width Printing (ESC R), 24  
Turn off Triple-Height Printing (ESC f), 25  
Turn Off Underline (ESC Y), 24  
Turn on Double-Height Printing, 25  
Turn on Double-Width Printing (ESC U), 24  
Turn on Triple-Height Printing (ESC e), 25  
Turn on Triple-Width Printing (ESC g), 25  
Turn on Triple-Width Printing (ESC h), 25  
Turn on Underline (ESC X), 24

## U

Unimplemented Commands, 31

- confirm print end (ESC b), 31
- paper out detection control (ESC O), 31
- paper out detection control (ESC Z), 31
- select Hiragana ANK mode (ESC &), 31
- select Katakana ANK mode (ESC '), 31
- set color mode (ESC c), 31
- set single paper orientation (ESC T), 31

## V

Vertical Motion Command Functions, 15  
Vertical Motion Commands, 23

- execute vertical tab (VT), 24
- feed forward n/120" (ESC % (#) 5 n), 23
- form feed (FF), 23
- line feed (LF), 23
- reversed form feed n/120" (ESC %8 n and ESC #8 n), 23
- set 1/6 inch line spacing (ESC 6), 23
- set 1/8 inch line spacing (ESC 8), 23
- set bottom margin (ESC G n1 n2), 24
- set form length by lines (ESC C n), 23
- set form length in inch by 1/120" (ESC J n1 n2), 23
- set line space by 1/120" (ESC %(#) 9 n1 n2), 23
- set page length (ESC F n1 n2), 23
- set top of form (ESC 5), 23
- set vertical movement in lines (ESC VT n1 n2), 23
- set vertical tab (DC4), 23





256482-001A