# How to configure P8000 with TN5250 emulation

Open the browser and type printer IP address. User is root and no password then ok

Click on TN5250\TN3270

Type AS400 IP address then Printer Name then *none and click on Auto Connect then SUBMIT

Click on REBOOT and device will be created on the AS400

AS400 Printer Device Status (Active) and Spooler (Started)


```
Untitled - Reflection - IBM 5250 Terminal                    —    □    ×
File  Edit  Connection  Setup  Macro  Window  Help

                    Work with Configuration Status          S652003A
                                              02/04/21   10:23:39
Position to  . . . .  _____      Starting characters

Type options, press Enter.
  1=Vary on   2=Vary off    5=Work with job    8=Work with description
  9=Display mode status     13=Work with APPN status...

Opt  Description        Status              -------------Job-------------
 __   PRTROBERT         VARIED ON
 __   PRT01             VARIED OFF
 __   PRT8SNMP          ACTIVE/WRITER        PRT8SNMP    QSPLJOB    412867
 __   PRT8TN            ACTIVE/WRITER        PRT8TN      QSPLJOB    446149
 __   PRT809            VARY ON PENDING



                                                               Bottom
Parameters or command
===>
F3=Exit    F4=Prompt    F12=Cancel    F23=More options    F24=More keys

1      »                                                         11/29
11, 29            IBM 5250 Terminal - 10.254.39.2 via Telnet            NUM
```



```
Untitled - Reflection - IBM 5250 Terminal                    —    □    ×
File  Edit  Connection  Setup  Macro  Window  Help

                       Work with All Printers

Type options, press Enter.
  1=Start    2=Change    3=Hold    4=End    5=Work with    6=Release
  7=Display messages    8=Work with output queue

Opt  Device     Sts   Sep   Form Type   File      User      User Data
 █    PRT01      END
 _    PRT8SNMP   STR   *FILE  *ALL
 _    PRT8TN     STR   *FILE  *ALL
 _    PRT809     END
 _    P5IPDSCSC  END
 _    P5000      END
 _    P5000AFP   END
 _    P5000SCS   END
 _    P7IP246    END
 _    P8IRV73    END
 _    P8SNMP     END
                                                          More...
Parameters for options 1, 2, 3, 4, 6 or command
===>
F3=Exit    F11=View 2    F12=Cancel    F17=Top    F18=Bottom    F24=More keys

1      »                                                         8/3
8, 3             IBM 5250 Terminal - 10.254.39.2 via Telnet            NUM
```